



**JGD 25V, C, SE & BF DOWNFLOW
SELECTIVE WARM AIR HEATERS**

STB (56)

UDC 6973

**Installation & Maintenance
Instructions**

Publication No. JA 20/6.

The JGD25V is a Gas Fired Forced Warm Air Heater produced in three variants:

JGD25VC MKIV Con conventionally fired model with manual ignition.

JGD25VSE MKIV SE-Duct Model with electric ignition.

JGD25VBF MKIV Balanced flue model with electric ignition.

All three variants have an output of 25,000 Btu/h (6,300k.cal/h. 7.23kW/h).

WATER HEATING The JGD25V Con conventionally fired model provides for the optional external fitting to either side of an Ascot type 303C or a Maxol type JS. 30 Water Heater. Water Heater Fittings Kits, WK25/303 and WK25M respectively, are available from Johnson & Starley Ltd.

Page No.

CONTENTS

1	HEATER COMPONENTS CHECK	1
2	PREPARATION & WARM AIR INSTALLATION REQUIREMENTS	1
3	FITTING SEQUENCE	3
4	RETURN AIR	4
5	GAS SUPPLY	4
6	ELECTRICAL CONNECTIONS	4
7	COMMISSIONING	4
8	SERVICING AND FAULT FINDING	5
9	MAINTENANCE	6
10	DIMENSIONS	7
11	SPECIFICATION	8
12	WIRING DIAGRAMS	9
13	SPARE PARTS LIST	10
		11

The positioning of the heater base duct or warm air plenum should be adjusted to give the required clearances from any combustible materials. In the case of a balanced flue or S. E. - Duct installation the base duct or warm air plenum should be positioned in the correct relative position to any pre-cut holes (SEE FIGS. 4, 5 & 6).

It is recommended that the access door to the heater cupboard be large enough to permit the heater removal. Service access required to the front of the heater is 18" (457mm).

Back	2"	(51mm)
Sides	2"	(51mm)
Front	3"	(77mm)


a) HEATER INSTALLATION CLEARANCES - from Combustible Materials.

2. PREPARATION & WARM AIR INSTALLATION REQUIREMENTS

ITEM	QTY.	ITEM	QTY.
JGD25VC MK.IV	1	JGD25VSE & BF MK.IV K	1
Draught Diverter	1	Asbestos Rope Sealing Rings	2
Draught Diverter Bracket	1	The Rods with Nuts	2
Screws For Draught	2	Clamping Brackets	2
Nuts Diverter Bracket	2	Eye Bolts	2
Washers Fitting	4	Washers	4
Combustion Air Inlet Baffle	1	The Rods with Nuts	4
		Clamping Brackets	2
		Eye Bolts	2
		Washers	2
		The Rods with Nuts	2
		Asbestos Rope Sealing Rings	2

THE FOLLOWING ARE ENCLOSED WITH ALL HEATERS

1. HEATER COMPONENTS CHECK



b) INSTALLATION ON SUSPENDED FLOORS.

Combustible floors must be insulated from the heater. When a base duct is used insulation can be provided by a suitable non combustible material i. e. asbestos board (SEE FIG. 1).




FIG 1

When an underfloor warm air plenum is used insulation can be provided by using a J. & S. Base Tray - BT25 (SEE FIG. 2 & 3).




FIG 2




FIG 3

c) INSTALLATION ON SOLID FLOORS

An underfloor warm air plenum may be used in a solid floor. Adequate insulation should be provided for both plenum and ducting.

d) ELECTRICAL

A 220/240 Volt socket is required adjacent to the heater. The 24 volt room thermostat wires should be brought into the heater cupboard and sufficient length left to enable connection to be made to thermostat socket which is on the right hand side of the heater.

e) SUMMARY OF REQUIREMENTS AND RECOMMENDATIONS FOR WARM AIR SYSTEMS.

Regulations of importance concerning Gas-Fired Warm Air Systems:

Building Regulations.

British Standard Code of Practice CP. 332 Part 4.

Institute of Electrical Engineers Regulations (External Wiring).

Johnson & Starley publish a Warm Air Design Manual - Publication JA. 63 which is obtainable upon request.

Information in the following paragraphs has been extracted from these regulations and, in some cases, amplified in the light of specific requirements of the JGD25V.

f) VENTILATION AND COMBUSTION AIR TO HEATER COMPARTMENT - MINIMUM REQUIREMENTS.

JGD25VC

Low Level Grille, Free Area 25 sq. ins.

High Level Grille, Free Area 13 sq. ins.

Low Level Grille only, Free Area 13 sq. ins.

Conventionally flued model with Water Heater fitted.

Low Level Grille, Free Area 36 sq. ins.

High Level Grille, Free Area 18 sq. ins.

g) FLUES.

Building Regulations can be satisfied by a variety of materials. Lightweight asbestos is commonly used. NOTE that untreated asbestos is acceptable only for flues not exceeding 20 ft. serving the air heater only (no water heater). Asbestos flues of over 20 ft., or of any length - if serving air heater and water heater, must be treated with vinyl acetate or a similar protection.

JGD25VC MK.IV (Fig.9 Page 8)

a) Fit the combination flue box and draught diverter over the top spigot at the back of the heater with its long spigot upwards.

b) Fit the heater flue bracket over the adaptor and secure to the heater cabinet with nuts and bolts provided. Tighten bracket to ensure firmness. To facilitate fitting the flue bracket, pull filter tray forward.

c) With the notice "TOP" uppermost, fit the combustion air inlet baffle to the bottom spigot at the rear of the heater. Carefully lift the heater into the heater cupboard and bolt it squarely on the base duct, or set it on the insulating frame for suspended floors or sunken warm air plenum for solid floors. Make sure no leakage of air occurs between the heater and base duct.

e) Complete the flue connection, using a split clip, to the heater flue box. Flue installations should comply with Gas Board requirements and Building Regulations.

NOTE: The flue pipe must be supported to relieve its weight from the heater.

JGD25BF MK.IV K (Fig.10 Page 8)




FIG 4

The terminal is suitable for walls up to 14" (356mm) thick, the flue installation should comply with Gas Board requirements and Building Regulations.

a) Prepare a finished opening in the wall to the dimensions and position shown in Figs. 4 & 5.

b) Fix the two Eye Rawbolts - Type AE-3/16" securely into the wall at positions 'A' - 'A'. The flue terminal box is a standard length of 14", hence for an 11" cavity wall prepare two asbestos backed wood distance pieces about 3" thick and the same width as the connecting box to fit between the wall and the back of the connecting box in the positions shown in Fig. 5.

For other types of wall, distance pieces of appropriate thickness should be used.


c) Position the flue terminal box in the wall opening and fit the distance pieces as shown. Fit the cast terminal grille to the flue terminal box making sure that it is level with the outside surface of the wall. Do not overtighten the holding screws. Insert the threaded ends of one pair of the rods through the connecting box clamp bar and engage the hook ends into the Rawbolt eye. Dependant upon wall thickness these rods may require shortening. Start the tie-rod nuts and carefully tighten each side so that the asbestos strips and wood distance pieces are held firmly. Check that the connecting box is square to the wall both vertically and horizontally.

d) Insert the clamp brackets through the slots in the side of the heater cabinet. Fit the soft asbestos sealing washers on both spigots at the rear of the heater and carefully lift the heater into the cupboard as detailed in JGD25VC (d) so that the spigots enter the sockets in the connecting box.

e) Insert the threaded end of the other tie rods through the clamp brackets and place the hook ends in the slots on the connecting box clamp bar.

Start the tie-rod nuts and carefully tighten each side so that the asbestos washers compress evenly to form an effective seal between the back of the heater and the Balanced Flue connecting box.

CONNECTION DETAILS FOR SE-DUCT APPLICATION



These instructions refer to SE-ducts constructed from concrete blocks or similar materials. Information for fitting and securing heaters to SE-ducts constructed of light-weight materials e.g. asbestos board, is available from Johnson & Starley.

NOTE: The concrete plinth for the heater must be so formed that the distance from its levelled top to the centres of SE-duct entries 'A' and 'B' is exactly to the measurements shown in Fig. 6 - unless this is correct, the heater will fail to fit the SE-duct flue.

a) Cement a piece of 5" inside diameter light duty asbestos cement pipe into each hole in the SE-duct, at 'A' and 'B' - Fig. 6. The outer ends of these pieces to be flush with the outer surfaces of the SE-duct cladding. The inner end of the lower pipe 'B' to be flush with the inner surface of the SE-duct and the end of the upper pipe 'A' to project 1" into the SE-duct.

b) Fix an Eye Rawlbolt Type AE-3/16" into the SE-duct cladding at each position 'C' and ensure firm anchorage.

c) Insert the clamp brackets through the slots in the sides of the heater cabinet. Fit the threaded ends of the tie-rods through the holes provided and start nuts on threads.

d) Fit the soft asbestos sealing washers on both spigots at the back of the heater, bolt securely to the base duct with the bolts provided, carefully lift on to the concrete plinth and slide into the compartment so that the spigots enter the asbestos cement pipes.

e) Hook each tie-rod into the Rawlbolt eye and carefully tighten each side so that the asbestos washers compress evenly to form an effective seal between the back of the heater and the SE duct.

SPECIAL SE-DUCT OR "U" DUCT FITTINGS

Heaters fitted near the bottom of a SE-duct or "U" duct may require a special adaptor between the heater and the duct. Information is available on this application from Johnson & Starley.

4. RETURN AIR.

Positive return air duct should now be installed. (SE-duct and balanced flue heater may be installed without positive return air.)

5. GAS SUPPLY

A 1/2" Gas Cock is supplied and connection is made from the right hand side. The gas supply pipe should have a minimum diameter of 1/2" depending on length of run and installation should conform to Local Gas Board requirements and Building Regulations.

6. ELECTRICAL CONNECTIONS.

a) MAINS SUPPLY The heater is supplied complete with mains lead which may be connected either side to a 5A, fused plug suitable for the mains socket provided in the heater cupboard.

b) ROOM THERMOSTAT. A 24V two pin socket is provided on the right hand (facing) side of the heater. The two pin plug provided should be connected to the 24V room thermostat wires brought into the heater cupboard and the plug fitted to the heater socket.

c) TIME CONTROL. The Horstmann type 423 Emerald time control is fitted as standard and pre-wired into the heater. No on site electrical connections are necessary.

7. COMMISSIONING.

a) Check that provisions for combustion and ventilation air to heater cupboard are in accordance with para.2(f) and that return air path to heater is adequate and free of obstruction.

b) Check that at least two registers are open.

c) Set room thermostat anticipator to 0.5, and set thermostat pointer to OFF.

d) Check that both Fan and Limit Switches are set correctly, see specifications for settings.

NOTE: Some heaters are fitted with an automatic Fan Timer Switch, the settings of which are not adjustable.

e) Fit gas pressure gauge to test point on burner manifold.

f) Turn on gas supply and bleed off air.

g) Switch on electricity.

h) Identify whether the heater installed is Electric or Manual Ignition and follow the appropriate lighting instructions inside heater lower door.

NOTE: The circulating air fan operates a short time after main burner has lit, i.e. when sufficient heat is available in heat exchanger—and shuts down a short time after main burner has gone out, i.e. when all useful heat is removed from the heat exchanger.

i) PILOT FLAME ADJUSTMENT

May be necessary whilst commissioning the heater. The pilot flame should be adjusted so that it just envelopes the thermocouple tip. To adjust the pilot flame remove the screw dust cap on Gas Control. SEE FIG. 7. Within the turret will be found a small adjusting screw which increases or decreases the gas flow to pilot burner if screwed anti-clockwise or clockwise respectively.

j) BURNER BAR PRESSURE

Check burner bar pressure at gas manifold or gas rate at gas meter and re-check after 20 mins. Adjustment is carried out by removing the dust cap of the gas pressure adjustment point. SEE FIG. 7. After removing the cap another screw can be seen which if screwed clockwise increases the gas flow and if screwed anti-clockwise decreases the gas flow.

k) TIME CONTROL

Set time control as manufacturer's instruction included with the heater.





FIG 7

V8257 COMBINATION GAS CONTROL

SWITCH OFF ELECTRICAL SUPPLY TO HEATER BEFORE SERVICING

SYMPTOM

POSSIBLE CAUSE

REMEDY

SYMPTOM	POSSIBLE CAUSE	REMEDY
a) Pilot will not light	i) No gas supply to heater. ii) Gas supply pipe not purged. iii) Pilot orifice restricted.	Break gas cock union and listen for escape Break gas cock union until gas is detected. Clear pilot orifice carefully with soft cop- per fuse wire. Check for soundness.
b) Pilot lights but goes out on releasing control knob.	i) Connection between thermocouple and gas control not secure. ii) Faulty Pilotstat or Gas Control. iii) Faulty Thermocouple. iv) Pilot flame not sufficient.	Check connection is secure. Replace Pilotstat Replace Thermocouple. Adjust as in 7.
c) Pilot lights but goes out after normal operation.	As b above.	As b above.
d) Pilot alight but main burner not igniting.	i) Mains electrical supply not connected to heater. ii) Gas control knob not in ON position iii) Controls not calling for heat iv) 2A. fuse (if fitted) failed	Check mains supply. Check position of knob. Check time control and room thermostat are calling for heat. Replace and if failure occurs again check external room thermostat leads for shorting to earth.
e) Main burner lights but fan fails to operate.	v) Loose connection on room thermostat, limit control, gas control head, time control or transformer. vi) Transformer open circuited. vii) Gas control operator faulty viii) Gas control governor faulty ix) Limit control faulty x) Faulty room thermostat or external wiring.	Check all connections for soundness. Check with test meter and replace transformer if necessary. Replace operator. Replace governor. Check operation by shorting across control connections. Fit temporary loop in heater room thermostat socket. If heater fires, external circuit or room thermostat is faulty.
f) Main burner operating intermittently with fan operating.	i) Loose electrical connection on fan control or fan plug and socket. ii) Fan control settings incorrect. iii) Faulty fan assembly	Check connections for soundness. Check settings are 100° F OFF 20° F DIFF. Replace assembly ensuring that pressure is not placed on impeller or motor. Balance of assembly may be distorted. Replace component.
g) Main burner operating with intermittent fan operation.	v) If fan timer is fitted room thermostat anticipator setting low. vi) Burner bar pressure not correct. i) Gas rate and burner bar pressure high. ii) Limit control setting not correct. iii) Air filter or return air path restricted. iv) Excessive number of registers closed.	Adjust anticipator setting to 0.65A. Adjust pressure if necessary. Check gas rate and burner bar pressure. Adjust to 220° F. Check filter for cleanliness and return air for obstruction. Open additional register. Check gas rate and burner bar pressure. Check settings are 100° F OFF 20° F DIFF. As g(ii) above.
h) Fan continues running for excessive period or operates intermittently after main burner shuts down.	i) Fan control settings incorrect. ii) Fan control settings incorrect.	As g(ii) above.
i) Noisy operation.	i) Gas pressure high. ii) Noisy fan motor.	Check burner bar pressure. Replace fan motor.

Lighting the heater and allowing to run for a short time checks these controls.

AUTOMATIC CONTROLS INSPECTION

Ensure pilot flame is as described in section 7.

PILOT FLAME CHECK

Attach a gas pressure gauge to gas pressure test point on burner manifold, check pressures and confirm by gas rate check at the meter. See pressure table on Page 9. If gas pressure needs adjustment refer to section 7f.

GAS PRESSURE CHECK

Remove complete air filter assembly from the heater. Remove polyurethane filter from filter tray and wash in lukewarm water and detergent. Squeeze filter to remove most water and replace.

AIR FILTER CLEANING

When fan has been removed from the heater, remove all dust etc. from both Fan Impeller and Fan Motor. Care must be taken whilst cleaning both items that the fan balance is not disturbed.

Remove Fan Assembly.

FAN AND FAN MOTOR CLEANING

Operation of igniter switch will check if glow coil is operational. When burner bar is removed, inspect glow coil to ensure it is in good condition.

GLOW COIL INSPECTION (MODELS JGD25VE & BF)

The only thing that should need inspection on the thermocouple is the contact to the Gas Control, ensure that this contact is clean. To tighten this contact to the Gas Control, screw in finger tight then another 1/4 turn.

THERMOCOUPLE

Great care must be taken when cleaning the pilot injector orifice that it is not damaged or enlarged. To clean the orifice, pass soft thin copper fuse through the orifice, this is sufficient to clean out any foreign matter which may have formed.

Remove pilot injector

PILOT INJECTOR CLEANING

Great care must be taken when cleaning the orifice that it is not damaged or enlarged. When the injector has been removed, clean injector orifice by passing soft copper fuse wire through, this is sufficient to remove any foreign matter which may have gathered in the orifice.

Remove main injector(s)

MAIN INJECTOR CLEANING

Upon removal, the burner merely requires the gentle removal of any dust which may have accumulated. Under no circumstances should the burner holes be enlarged or distorted.

Remove burner

MAIN BURNER CLEANING


Maintenance is recommended annually and should cover the following:-

SWITCH OFF ELECTRICITY, REMOVE MAINS PLUG AND TURN OFF HEATER GAS COCK

9. MAINTENANCE

- f) Room temperatures too high or too low.
- g) Heater switches on and off outside required periods.
 - i) Time control motor running slowly. Replace time control.
 - ii) Time control tappets slipping. Replace time control.
 - iii) Time control tappets not set in correct sequence. Refer to time control operating instructions and set tappets accordingly, i.e. No.1 on in the morning. No.2 off in the morning. No.3 on in the afternoon. No.4 off in the afternoon.
- h) Room thermostat out of calibration. Re-calibrate.
- i) Incorrect siting of room thermostat. Re-position room thermostat if necessary.
- ii) Heater gas rate low. Check and adjust gas rate if necessary.
- iii) Insufficient return air or relief. Check return air path for size and obstruction. Fit relief grille to areas with no positive return air collection.
- iv) Heater gas rate low. Check and adjust gas rate if necessary.
- v) Room thermostat out of calibration. Re-calibrate.
- vi) Heater gas rate low. Check return air path for size and obstruction. Fit relief grille to areas with no positive return air collection.
- vii) Time control motor running slowly. Replace time control.
- viii) Time control tappets slipping. Replace time control.
- ix) Time control tappets not set in correct sequence. Refer to time control operating instructions and set tappets accordingly, i.e. No.1 on in the morning. No.2 off in the morning. No.3 on in the afternoon. No.4 off in the afternoon.

JGD25VC MK IV CONVENTIONAL FLUE



SIDE ELEVATION

SIDE ELEVATION





FIG 9

JGD25VC

1. Air Filter
2. Grommet for electrical entry (both sides)
3. Thermostat connection socket (RH)
4. Gas connection entry (RH)
5. Securing Bracket
6. Draught Diverter
7. Combustion Air Inlet shield
8. Holes for Base Duct fixing bolts.

JGD25V SE MK IV K.



FRONT ELEVATION


PLAN

JGD25VSE

1. Clamping bracket
2. Tie rod and eye bolt
3. Air inlet Baffle
4. Asbestos rope sealing rings.

1. Cavity sealed all round
2. Balanced flue terminal
3. Distance piece
4. Asbestos rope sealing rings
5. Tie rod and eye bolt
6. Tie rod
7. Clamping bracket.

FIG 10



SIDE ELEVATION

JGD25VBF MK IV K BALANCED FLUE

FIG 11

11. SPECIFICATION

- Electrical Supply 220-250 Volts, 50 cycles, 5 amps
- Mains Connection 6ft. external lead provided, high temperature P.V.C. sheathed.
- Gas Connection $\frac{3}{4}$ " B.S.P. FEMALE.
- Gas Cock $\frac{3}{4}$ " UNION, provided.
- Room Thermostat 24 Volt Plug and Socket on cabinet side.
- Room Thermostat 24 Volt type required.
- Time Control Horstmann type 423 Emerald as standard, 4 taps, ON, OFF, ONE CYCLE AND TWO CYCLE selector and override button.
- Transformer 20VA, 24V, Westool type TD-77-44PL (Model JGD25C), 20VA, 24V, Honeywell type RWD667 (Models JGD25VBF and JGD25VSE).
- Limit Switch Upper: Honeywell LA069C, 220° F. OFF TEMP. DIFFERENTIAL 25° F. Fixed. Lower: Honeywell LA068C, Fan OFF 100° F. DIFFERENTIAL 20° F. I. e. FAN ON 120° F.
- Fan Switch Honeywell S876 A. B.
- Fan Timer Switch Honeywell S876 A. B.

- Combination Gas Control Honeywell V8257 (24V).
- Thermocouple Honeywell Q309.
- Pilot Burner Honeywell Q314A.
- Glow Coil Honeywell 388700 F. I.
- BOS. 345 (Models JGD25VBF and JGD25VSE).
- Ignition Switch Honeywell ZPL/9004.
- Ignition Fuse (Models JGD25VBF & JGD25VSE).
- 10 amp. (Models JGD25VBF and JGD25VSE).
- Circuit Fuse 24V, 2amp x $1\frac{1}{2}$ " (32mm) cartridge.
- Fan Double entry centrifugal fan with an integral motor. Type 71D2T - Airflow - Developments.
- Fan Motor Type BC. 1504D, 1 $\frac{1}{2}$ MF - A. E. I. Chrome diffused steel, welded. Heat Exchanger Socket for 4" (101mm) I. D. Light weight asbestos. Cabinet Sheet steel, white stove enamel with internal radiation shields. Air Heater without flue fittings - 86 lbs. Weight For use when heater installed on combustible floor with under-floor plenum (optional extra).






FIG 13

JGD 25V (JXD 25V) Conventionally flued MK.IV		JGD 25V (JXD25V) BF and SE MK.IV K		
GAS GROUP	INJECTOR SIZE	GAS PRESSURE	GAS GROUP	
G3	IN.	MM.	IN.	
G4	IN.	MM.	IN.	
G5	IN.	MM.	IN.	
G6	IN.	MM.	IN.	
NAT	IN.	MM.	IN.	
PROP				
G3	1.97	5.00	1.5	
G4	1.97	5.00	1.8	
G5	1.97	5.00	2.1	
G6	2.13	5.40	1.9	
NAT	0.98	2.5	6.5	
PROP				
INPUT		33,000 Btu/h. (8,310kcal/h. 9.67kW/h)	GAS RATE	
OUTPUT		25,000 Btu/h. (6,300kcal/h. 7.23kW/h)	NATURAL GAS	
			TOWN GAS	
			33 cu. ft/hr.	
			66 cu. ft/hr.	

JGD 25V WITH HONEYWELL L4068C FAN SWITCH



JGD 25V WITH HONEYWELL 5876AB FAN TIME SWITCH



SPARE PARTS FOR MODELS JGD25VC MKIV AND JGD25VBF & SE MKIV K DOWNFLOW

SELECTIVE WARM AIR HEATERS

G. C. NUMBER	MAKERS PT. NO.	DESCRIPTION	QTY.
38. 85. 72	71D2T	Air circulating fan with integral motor. Amp-10k cap and earth wire. BOS. 106 Airflow Developments.	1
23. 35. 05	TD-77-A4P1. BOS. 372	Westool Transformer 20VA. 24 Volt. Type	1
38. 50. 75	L4069C 1066	Honeywell Overheat Limit Control (Lower Location) BOS. 105.	1
22. 95. 49	T29/3390	Other Limit Control (Upper Location) BOS. 141	1
	L4068C 1026	Honeywell Fan Control BOS. 104	1
	S876AB	Honeywell Fan Timer Switch BOS. 382	1
22. 95. 02	JGD25/770Z	Lighting Port Cover	1
39. 01. 38	Q309A. 1236	Honeywell Thermocouple 30" long BOS. 36	1
	BOS. 290	Burner Bar Assembly (Pohidoro-Multi Gas)	1
	BOS. 290/3	Main Injector-Towns Gas-Gas Groups 3, 4 & 5	1
	JGD25V/MKIV/755Z	Main Injector-Towns Gas-Gas Group 6	1
	2555W.	Thermostat Plug and Socket	1
	BOS. 384	Glass Fuse 2 amp rating 1 1/2" long.	1
22. 95. 80	BOS. 139	Heat Exchanger Gasket (Asbestos Foil Faced) 6 11/16"-dia. x 1 1/8"	1
22. 95. 83	BOS. 97	Heat Exchanger Gasket (Asbestos) 6 11/16" od. x 5 1/8" id. x 1 1/8"	1
22. 95. 84	BOS. 98	Heat Exchanger Gasket (Asbestos) 8" od. x 6 23/32" id. x 1/2"	1
	Alternative for JGD25VBF & SE MKIV K only.		
	BOS. 356	Burner bar assembly (Ketting-Multi-Gas)	1
	BOS. 491	Main injectors-Towns Gas-Gas Groups 3&4	2
	BOS. 493	Main injectors-Towns Gas-Gas Groups 5&6	2
23. 35. 05	RWD667	Honeywell Transformer 20VA. 24 Volt and 2.5 Volt.	1
	388700F1	Honeywell Glow Coil Assembly	1
22. 95. 58	ZPL-9004	Honeywell Micro Switch	1
	BOS. 369	Glass Fuse 10 amp Rating 1 1/2" long.	1
	(Radio Spares) to BS.2950A.		
	Alternative Items required for Natural Gas Heaters		
	BOS. 290/3A	Main injector for JGD25VC MK.IV	1
	BOS. 492	Main injector for JGD 25VBF & SE MK.IV K	2
	390686/4	Pilot Injector. Honeywell BCR.18	1
	42000233/001	Gas Governor Spring.	1

JGD25VC MK.IV Only

Alternatives

Alternatives

Telephone: 62881-6

Johnson & Starley Ltd Rothersthorpe Crescent, Northampton NN4 9JF